

Aliph

Jawbone

Apex

Digital E2GO

Apple

iPhone / iPod / iPod Classic / iPod Mini / iPod Nano / iPod Photo / iPod Touch / iPod Video

Audiovox

CDM8400 / CDM8410 / CDM8450 / CDM8455 / CDM8610VM / CDM8615 / CDM8615CS / CDM8900 / CDM8910 /
CDM8910BM / CDM8910VM / CDM8910VW / CDM8912 / CDM8915 / CDM8930 / CDM8940 / CDM8940VW / CDM9200 /
CDM9900 / CDM9950 / CDM9950SP / PDM8920 / PM8912 / PM8920 / PPC-6700 / PPC-6800 Mogul / SMT 5600 / VI600

Bang & Olufsen

EarSet 2

Belkin

Skype WiFi F19900GN-SK / WiFi Phone

BenQ-Siemens

EU hhb 505 / EU hhb 515 / EU hhb 535 / EU hhb 600

Blackberry / RIM

All Models

BlueAnt

X3 Micro / Z9

Cowon

A2 / iAudio A2 / M3 20Gb / M3 40Gb / M3L 20Gb / X5

Creative

Creative XMOD / MuVo Slim / MuVo Slim XMOD / Nomad Jukebox 2 / Nomad Jukebox 3 / Nomad Jukebox Zen NX /
Nomad Jukebox Zen USB 2.0 / Nomad Jukebox Zen Xtra / Stone / Xmod / Zen / Zen 16GB / Zen 2GB / Zen 32GB / Zen
4GB / Zen 8GB / Zen Micro / Zen Micro Photo / Zen MuVo 2 / Zen MuVo 2 FM / Zen Nano / Zen Nano Plus / Zen Neon
/ Zen Neon 2 / Zen PMC / Zen Portable Media Center / Zen Stone / Zen Touch / Zen V / Zen V Plus / Zen Vision

Dash

Dash

Dell

Axim X3 / Axim X30 / Axim X3i / Axim X50 / Axim X50v / Axim X51 / Axim X51v / Pocket DJ

Disney

Mix Max 19012 / Mix Max DS19005

Dopod

565 / 566 / 575 / 577W / 585 / 586W / 595 / 686 / 696 / 696i / 700 / 818 / 818 Pro / 828 / 838 / 838 Pro / 900 / C500 / C720W / C730 / C800 / D810 / M700 / P100 / P800W / U1000

E-Plus

PDA IV

Eten

Glofish M700 / Glofish X500 / Glofish X800

Garmin

Edge / Edge 205 / Edge 305 / Edge 605 / Edge 705 / Forerunner 205 / Forerunner 301 / Forerunner 305 / iQue 3200 / iQue 3600 / Nuvi 200 / Nuvi 250 / Nuvi 260 / Nuvi 270 / Nuvi 300 / Nuvi 310 / Nuvi 350 / Nuvi 360 / Nuvi 370 / Nuvi 5000 / Nuvi 600 / Nuvi 610 / Nuvi 650 / Nuvi 660 / Nuvi 670 / Nuvi 680 / Nuvi 710 / Nuvi 750 / Nuvi 760 / Nuvi 770 / Nuvi 780 / Nuvi 850 / Nuvi 880 / Quest / StreetPilot C310 / StreetPilot C330 / StreetPilot C340 / StreetPilot C510 / StreetPilot C530 / StreetPilot C550 / StreetPilot C580 / StreetPilot i2 / StreetPilot i3 / StreetPilot i5 / Zumo 400 / Zumo 450 / Zumo 500 / Zumo 550

Gigabyte

GSmart i120 / GSmart i300 / GSmart MS800 / GSmart MW700 / GSmart Q60 / GSmart T600

Grundig

GR980

Helio

Kickflip

HP

iPAQ 110 / iPAQ 111 / iPAQ 210 / iPAQ 211 / iPAQ 500 / iPAQ 510 / iPAQ 512 / iPAQ 514 / iPAQ RW6800 / iPAQ RW6828 / iPAQ RX4000 / iPAQ RX4200 / iPAQ RX5700 / iPAQ RX5910 / iPAQ RX5915 / iPAQ Travel Companion / PhotoSmart R927 / XV6700

HTC

5800 / 6700Q / 8310 / Advantage / Amadeus / Ameo / Apache / Artemis / Athena / Breeze / Cavalier / Charmer / Dash / Excalibur s620 / Faraday / Feeler / Fusion / Galaxy / Herald / Hermes / Hermes 100 / Hermes 200 / Hermes 300 / Himalaya / Hurricane / Kaiser / Libra / Love / Magician / Mogul (PPC-6800) / MTeoR / Muse / Orange M650 / Orange M700 / Orange SPV C100 / Orange SPV C500 / Orange SPV C550 / Orange SPV C600 / Orange SPV C700 / Orange SPV E650 / Orange SPV M3000 / Orange SPV M3100 / Orange SPV M500 / Orange SPV M5000 / Orange SPV M600 / Oxygen / P3050 / P3300 / P3350 / P3600 / P4350 / P6300 / Panda / Prophet / S310 / S620 / S620C / S621 / S630 / S710 / S720 / SDA / Shadow / Siemens SX-56 / SoftBank X01HT / SP5m / T-Mobile MDA / T-Mobile MDA compact III / T-Mobile MDA Pro / T-Mobile MDA Vario / T-Mobile MDA Vario II (HERM 300) / T-Mobile SDA (UK) / T-Mobile SDA Music / T-Mobile SDA Music 2 / T-mobile Wings / Tilt 8925 / Tornado / Touch / Touch Cruise / Touch Dual / Touch Slide / Trinity 100 (P3600) / Typhoon / TyTN / TyTN II / Universal / UTStarcom PPC-6700 / Vodafone V1240 / Vodafone v1605 / Vodafone V1640 / Vodafone VPA Compact / Vodafone VPA IV / Vogue / Vox / Wallaby / Wizard / X7500 / X7501 / XV6700

i-mate

Jam / JAMin / JAQ / JAQ3 / JAQ4 / JASJAM / JasJar / K-JAM / New Jam / PDAL / SP JAS / SP3 / SP3i / SP4m / SP5 / SP5m / SPL / Ultimate 5150 / Ultimate 6150 / Ultimate 7150 / Ultimate 8150 / Ultimate 9150

Insignia

2GB / 4GB / Amigo / NS-2N17r / NS-2V17 / NS-2V17b / NS-4V17 / NS-4V17b / NS-4V17r / NS-4V24 / NS-8V24 / NS-DA1G-Sport / NS-DA2G-Sport / NS-DV2G / NS-DV4G / NS-DVB4G / Sport 1GB / Sport 2GB

logear

GBE211 / GBHFK201W6 / GBMH201 / GBMHKIT / GBMHPODKIT

iRiver

B20 / Clix2 / H320 / H340 / iFP-590T / iFP-595T / iFP-599T / PMC-100 / T10 / T30 / T50 / T60 / X20

Jabra

A125s / BT2010 / BT2020 / BT3030 / BT620s

Jens of Sweden

MP-400 / MP-450 / MP-X

Kodak

DC4800 / DX6490 / DX7440 / DX7590 / DX7630 / EasyShare M1033 / EasyShare M763 / EasyShare M863 / EasyShare M873 / EasyShare M883 / EasyShare M893 IS / EasyShare P712 / EasyShare V1003 / EasyShare V1073 / EasyShare V1233 / EasyShare V1253 / EasyShare V1273 / EasyShare V530 / EasyShare V550 / EasyShare V570 / EasyShare V603 / EasyShare V610 / EasyShare V705 / EasyShare V803 / EasyShare-One / 4 MP / EasyShare-One / 6 MP / LS443 / LS633 / LS743 / LS753 / LS755 / M753 / M853 / M873 / M883 / P850 / P880 / Z730 / Z7590 / Z760

Krome

iQ700 / Navigator F1 / Spy

Kyocera

1135 / 1155 / 2119 / 2119b / 2135 / 2235 / 2255 / 2300 / 2325 / 2345 / 3200 / 3225 / 3245 / 3250 / 7135 / BLADE / E2000 / Flasher V7 / K10 Royale / K110 / K112 / K4130 / K433 / K433C / K433L / K434 / K434N / K440 / K444 / K454 / K454L / K454LC / K454N / K454NC / K480 / K493LC / K494 / K494LC / K494NC / K494XLC / K7 / K7 RAVE / K9 / K9 RAVE / KE413 / KE413c / KE414 / KE414c / KE423 / KE423C / KE424 / KE424c / KE433 / KE433c / KE434 / KE434C / Koi / KWC-2135 / KWC-2235 / KX1 / KX1i / KX1v / KX2 / KX413 / KX414 / KX424 / KX433 / KX434 / KX440 / KX444 / KX9 / KX9A / KX9B / KX9C / KX9D / KX9E / LINGO / M1000 / Mako / MILAN / OYSTR / PHANTOM / QCP2027 / QCP2035 / QCP2035A / RAVE / Royale / S4000 / SoHo / Tempo / WILD CARD

LG

1200 / AX275 / AX300 / AX380 / AX830 / AX8600 / C810 / CE110 / CG180 / CHOCOLATE / Chocolate 3 / Chocolate-Cherry / Chocolate-Green / Chocolate-Mint / Chocolate-Pink / Chocolate-Red / Chocolate-White / CU515 / CU575 / Dare / Decoy / EnV / EnV-Green / EnV-Orange / Env2 / FLARE / Glimmer / HBM-300 / HBM-500 / HBM-730 / KE820 / KE850 PRADA / KE970 / KG320 / KG800 / KG808 / KG810 / KG900 / KU800 / KU970 / KU990 / KU990R / LX1200 / LX150 / LX160 / LX165 / LX400 Blue / LX400 Burgundy / LX570 / MG800C / MUZIQ / MUZIQ- PINK / PM225 / PRADA KE850 / RUMOR / SCOOP / SHINE / TM510 / TRAX / U970 / UX300 / UX380 / UX830 / VENUS / VI125 / VOYAGER / VX10K / VX5400 / VX7000 / VX8350 / VX8500 / VX8550 / VX8560 / VX8600 / VX8610 / VX8700 / VX8800 / VX9100 / VX9400 / VX9700 / VX9900 / WAVE

Logitech

Mobile Express 980

Memorex

MMP8564A / MMP8565 1GB / MMP8567 / MMP8575 2GB / MMP8585 / MMP8620 / MMP8640

Microsoft

Zune

Motorola

270c / 280 / 280g / A668 / A70 / A732 / A780 / A910 / Blend / C232 / C290 / C305 / C331g / C332 / C333 / C362 / C363 / Deluxe / E1070 / E610 / E615 / E680 / E680i / E685 / E770v / E815 / G520 / H3 / H350 / H375 / H500 / H550 / H605 / H670 / H700 / H710 / H800 / H850 / H9 / HF820 / HS815 / HS820 / HS830 / HS850 / HT820 / i205 / i215 / i265 / i275 / i285 / i290 / i305 / i315 / i325IS / i355 / i415 / i425 / i455 / i500 / i530 / i550 / i560 / i580 / i605 / i615 / i670 / i700 / i710 / i730 / i733 / i736 / i760 / i830 / i833 / i835w / i836 / i850 / i855 / i860 / i870 / i876 / i880 / i885 / i920 / i930 / ic402 / ic502 / ic602 / ic902 / ic902 Deluxe / KRZR K1 / KRZR K1m / KRZR K3 / KRZR MAXX K3 / L2 / L6 / L6i / M300 / M500 / Ming A1200 / Ming A1200e / MOTO Q / MOTO Q music 9m / MOTO PHONE F3 / PEBL / PEBL E6 / PEBL U6 / RAZR H3 / RAZR MAXX Ferrari V6 / RAZR MAXX V6 / RAZR MAXX Ve / RAZR V3 / RAZR V3a / RAZR V3c / RAZR V3e / RAZR V3i / RAZR V3i DG / RAZR V3im / RAZR V3m / RAZR V3r / RAZR V3t / RAZR V3x / RAZR V3xx / RAZR V6 maxx / RAZR2 Q9h / RAZR2 Q9m / RAZR2 U9 / RAZR2 V8 / RAZR2 V9 / RAZR2 V9m / RAZRWIRE / RIZR Z3 /

RIZR Z6 / RIZR Z6c / RIZR Z6cx World Edition / RIZR Z6tv / RIZR Z8 / ROKR E1 / ROKR E2 / ROKR E6 / ROKR E8 / ROKR S9 / ROKR Z6 / ROKR Z6m / S805 / S9 / SLVR / SLVR i-mode / SLVR L6 / SLVR L7 / SLVR L7c / SLVR L7i / SLVR L9 / SLVR V8 / SLVR Z10 / T305 / T505 / T720i / T722 / T722i / T725 / The Buzz / Timeport 270 / V120 / V120c / V120e / V120t / V120x / V190 / V191 / V195 / V197 / V200 / V235 / V265 / V266 / V276 / V300 / V320 / V323 / V323i / V325 / V325i / V330 / V360 / V361 / V365 / V400 / V500 / V505 / V525 / V540 / V547 / V551 / V555 / V557 / V6 / V60 / V600 / V60c / V60g / V60i / V60t / V66 / V660 / V70 / V710 / V810 / W175 / W180 / W220 / W230 / W315 / W370 / W372 / W375 / W377 / W385 / W490 / W510 / Z Slider / Z8 / Z9

Netgear

Skype Phone

Nintendo

DS / DS Lite / Game Boy Advance SP

Nokia

1100 / 1101 / 1108 / 1110 / 1110i / 1112 / 1200 / 1208 / 1209 / 1221 / 1255 / 1260 / 1261 / 1600 / 1606 / 1650 / 1680 Classic / 2100 / 2112 / 2115i / 2116 / 2116i / 2118 / 2125 / 2125i / 2126i / 2128i / 2135 / 2255 / 2260 / 2270 / 2275 / 2280 / 2285 / 2300 / 2310 / 2505 / 252 / 252CC / 252N / 252NC / 2600 / 2600 Classic / 2610 / 2626 / 2630 / 2650 / 2651 / 2652 / 2680 Slide / 2760 / 282 / 2855 / 2865i / 3100 / 3105 / 3108 / 3109 / 3109 Classic / 3110 / 3110 Classic / 3110 Evolve / 3120 / 3120 Classic / 3125 / 3152 / 3155 / 3155i / 3200 / 3205 / 3210 / 3220 / 3230 / 3250 / 3285 / 3300 / 3310 / 3315 / 3330 / 3350 / 3360 / 3361 / 3390 / 3395 / 3410 / 3500 / 3500 Classic / 3510 / 3510i / 3520 / 3530 / 3555 / 3560 / 3570 / 3585 / 3585i / 3586 / 3586i / 3587i / 3588i / 3589i / 3590 / 3595 / 3600 / 3600 Slide / 3610 / 3620 / 3650 / 3660 / 5000 / 5070 / 5100 / 5110 / 5120 / 5125 / 5130 / 5140 / 5140i / 5160 / 5160i / 5165 / 5165i / 5170i / 5180i / 5185i / 5190 / 5200 / 5210 / 5220 XpressMusic / 5300 / 5300 Classic / 5310 / 5320 XpressMusic / 5500 / 5510 / 5610 / 5700 / 6010 / 6011i / 6015 / 6015i / 6016i / 6019i / 6020 / 6021 / 6030 / 6060 / 6061 / 6062 / 6070 / 6080 / 6085 / 6086 / 6088 / 6100 / 6101 / 6101 Classic / 6102 / 6102i / 6103 / 6108 / 6110 / 6110 Navigator / 6111 / 6115i / 6120 / 6120 Classic / 6120i / 6121 / 6121 Classic / 6125 / 6126 / 6130 / 6131 / 6133 / 6136 / 6150 / 6151 / 6152 / 6155 / 6155i / 6160 / 6160i / 6161 / 6161i / 6162 / 6162i / 6165i / 6168 / 6170 / 6185 / 6185i / 6190 / 6200 / 6205 / 6210 / 6210 Navigator / 6220 / 6220 Classic / 6225 / 6230 / 6230i / 6233 / 6234 / 6235 / 6235i / 6236i / 6250 / 6255 / 6255i / 6256i / 6260 / 6263 / 6265 / 6265i / 6267 / 6268 / 6270 / 6275i / 6280 / 6282 / 6288 / 6290 / 6300 / 6300i / 6301 / 6310 / 6310i / 6340 / 6340i / 6360 / 6370 / 6385 / 640 / 650 / 6500 / 6500 Classic / 6500 Slide / 6510 / 6555 / 6560 / 6585 / 6590 / 6590i / 6600 / 6600 Fold / 6600 Slide / 6610 / 6610i / 6620 / 6630 / 6650 / 6651 / 6670 / 6680 / 6681 / 6682 / 6708 / 6800 / 6810 / 6820 / 6820i / 6822 / 7070 Prism / 7088 / 7100 / 7110 / 7160 / 7190 / 7200 / 7210 / 7210 Supernova / 7250 / 7250i / 7260 / 7270 / 7280 / 7310 Supernova / 7360 / 7370 / 7372 / 7373 / 7380 / 7390 / 7500 Prism / 7510 Supernova / 7600 / 7610 / 7610 Supernova / 7650 / 770 / 7700 / 7710 / 7900 Crystal Prism / 7900 Prism / 8210 / 8250 / 8260 / 8265 / 8265i / 8270 / 8280 / 8290 / 8310 / 8390 / 8600 Luna / 8800 / 8800 Arte / 8800 Sapphire Arte / 8801 / 8810 / 8850 / 8850 Gold / 8855 / 8860 / 8890 / 8910 / 8910i / 9110 / 9110i / 9200 / 9210i / 9290 / 9300 / 9300i / 9500 / BH-100 / BH-200 / BH-201 / BH-202 / BH-203 / BH-204 / BH-205 / BH-206 / BH-207 / BH-208 / BH-300 / BH-301 / BH-301-LT / BH-302 / BH-303 / BH-500 / BH-501 / BH-600 / BH-700 / BH-700-BK / BH-700-WH / BH-701 / BH-800 / BH-800-BK / BH-800-WH / BH-801 / BH-803 / BH-900 / E50 / E51 / E60 / E61 / E61i / E62 / E65 / E66 / E70 / E71 / E90 / HDW-3 / HS-11W / HS-12W / HS-13W / HS-21W / HS-26W / HS-3W / HS-4W / HS-53W / HS-54W / HS-55W / HS-56W / LD-1W / N-Gage / N-Gage QD / N70 / N71 / N72 / N73 / N75 / N76 / N77 / N78 / N80 / N80 Internet Edition / N800 / N80ie / N81 / N810 / N810 WiMax Edition / N82 / N90 / N91 / N92 / N93 / N93i / N95 / N96 / PCS 5120 / Shorty / SU-27W / THR850 / THR880

O2

[XDA](#) / [XDA Atom](#) / [XDA Cosmo](#) / [XDA Exec](#) / [XDA II Mini](#) / [XDA IQ](#) / [XDA Mini](#) / [XDA Mini Pro](#) / [XDA Mini S](#) / [XDA Neo](#) / [XDA Orbit](#) / [XDA Orion](#) / [XDA Phone](#) / [XDA SP](#) / [XDA Stealth](#) / [XDA Trion](#) / [Xphone II](#) / [Xphone IIm](#)

Palm

[Centro](#) / [Centro 686](#) / [Centro 690](#) / [Gandolf](#) / [LifeDrive](#) / [Treo 500](#) / [Treo 500V](#) / [Treo 650](#) / [Treo 650 Wireless Headset](#) / [Treo 680](#) / [Treo 700p](#) / [Treo 700w](#) / [Treo 700wx](#) / [Treo 750](#) / [Treo 750v](#) / [Treo 755p](#) / [Treo 800p](#) / [Tungsten E](#) / [Tungsten E2](#) / [Tungsten T5](#) / [TX](#) / [Z22](#) / [Zire 31](#) / [Zire 72](#) / [Zire 72s](#)

Pharos

[505](#) / [525](#) / [525E](#) / [525P](#) / [PGS Phone 600](#) / [PTL 600](#)

Philips

[GoGear HDD082-17](#) / [GoGear SA3104-37](#) / [GoGear SA3105-37](#) / [GoGear SA3114-37](#) / [GoGear SA3115-37](#) / [GoGear SA3124-37](#) / [GoGear SA3125-37](#) / [GoGear SA6014-37](#) / [GoGear SA6015-37](#) / [GoGear SA6044-37](#) / [GoGear SA6045-37](#) / [GoGear SA6046-37](#) / [GoGear SA6065-37](#) / [GoGear SA6066-37](#) / [GoGear SA6085-37](#) / [GoGear SA6086-37](#) / [GoGear SA6087-37](#) / [GoGear SA6125-37](#) / [GoGear SA6145-37](#) / [GoGear SA6185-37](#)

Plantronics

[Discovery 925](#) / [Explorer 220](#) / [Explorer 360](#) / [Explorer 370](#) / [Pulsar 260](#) / [Voyager 815](#) / [Voyager 855](#) / [Voyager 885](#)

Qtek

[1010](#) / [1020](#) / [4040](#) / [8010](#) / [8020](#) / [8100](#) / [8200](#) / [8300](#) / [8310](#) / [9000](#) / [9100](#) / [9600](#) / [G100](#) / [S100](#) / [S110](#) / [S200](#) / [S300](#)

Qualcomm

[QCP2027](#) / [QCP2035](#) / [QCP2035A](#)

RCA

[Lyra Jukebox RD2762](#)

Rio

[Eigen](#) / [Karma](#) / [Nitrus](#)

Samsung

[4930](#) / [A580](#) / [A640](#) / [A990](#) / [Ace](#) / [Black Carbon](#) / [Black Jack](#) / [Blade](#) / [E330N](#) / [E350](#) / [E370](#) / [Heat](#) / [Hello Drift](#) / [Hello Heat](#) / [IP-A790](#) / [Jayhawk](#) / [Jitterbug](#) / [K3](#) / [K5JQ](#) / [Lime](#) / [M500](#) / [MM-5600](#) / [MM-A700](#) / [MM-A800](#) / [MM-A820](#) / [MM-A920](#) / [MM-A940](#) / [MM-A960](#) / [Nimbus](#) / [PM-A740](#) / [PM-A840](#) / [PM-A880](#) / [RL-A760](#) / [SCG-A610](#) / [SCH-A210](#) / [SCH-A310](#) / [SCH-A399](#) / [SCH-A475](#) / [SCH-A505](#) / [SCH-A509](#) / [SCH-A530](#) / [SCH-A539](#) / [SCH-A561](#) / [SCH-A563](#) / [SCH-A564](#) / [SCH-A565](#) / [SCH-A570](#) / [SCH-A591](#) / [SCH-A592](#) / [SCH-A595](#) / [SCH-A599](#) / [SCH-A603](#) / [SCH-A610](#) / [SCH-A630](#) / [SCH-A645](#)

/ SCH-A650 / SCH-A670 / SCH-A720 / SCH-A790 / SCH-A795 / SCH-A809 / SCH-A850 / SCH-A870 / SCH-A890 / SCH-A930 / SCH-A950 / SCH-A970 / SCH-A990 / SCH-i760 / SCH-N181 / SCH-N182 / SCH-N191 / SCH-N195 / SCH-N330 / SCH-N370 / SCH-N375 / SCH-R400 / SCH-R510 / SCH-U340 / SCH-U410 / SCH-U420 / SCH-U520 / SCH-U540 / SCH-U620 / SCH-U740 / SCH-U900 / SCH-V940 / SCH-X199 / SCH-X209 / SCH-X219 / SCH-X309 / SCH-X319 / SCH-X359 / SGH-A200 / SGH-A288 / SGH-A300 / SGH-A308 / SGH-A400 / SGH-A408 / SGH-A436 / SGH-A437 / SGH-A500 / SGH-A608 / SGH-A706 / SGH-A707 / SGH-A717 / SGH-A727 / SGH-A747 / SGH-A800 / SGH-A930 / SGH-B500 / SGH-C100 / SGH-C120 / SGH-C130 / SGH-C140 / SGH-C170 / SGH-C200 / SGH-C207 / SGH-C210 / SGH-C225 / SGH-C230 / SGH-C240 / SGH-C300 / SGH-C327 / SGH-C416 / SGH-C417 / SGH-C520 / SGH-D100 / SGH-D307 / SGH-D347 / SGH-D357 / SGH-D406 / SGH-D407 / SGH-D410 / SGH-D415 / SGH-D500 / SGH-D500C / SGH-D500E / SGH-D508 / SGH-D520 / SGH-D600 / SGH-D600E / SGH-D800 / SGH-D806 / SGH-D807 / SGH-D808 / SGH-D820 / SGH-D828 / SGH-D830 / SGH-D840 / SGH-D900 / SGH-D900i / SGH-E100 / SGH-E105 / SGH-E200 / SGH-E250 / SGH-E300 / SGH-E310 / SGH-E315 / SGH-E316 / SGH-E317 / SGH-E330 / SGH-E330N / SGH-E335 / SGH-E340 / SGH-E340E / SGH-E350 / SGH-E360 / SGH-E370 / SGH-E380 / SGH-E390 / SGH-E400 / SGH-E500 / SGH-E500 Versus / SGH-E570 / SGH-E590 / SGH-E600 / SGH-E630 / SGH-E635 / SGH-E700 / SGH-E705 / SGH-E710 / SGH-E715 / SGH-E730 / SGH-E740 / SGH-E760 / SGH-E770 / SGH-E780 / SGH-E790 / SGH-E800 / SGH-E840 / SGH-E870 / SGH-E900 / SGH-F300 / SGH-F500 / SGH-I600 / SGH-I607 / SGH-I620 / SGH-I710 / SGH-J600 / SGH-K258 / SGH-M300 / SGH-N200 / SGH-N288 / SGH-N400 / SGH-N500 / SGH-N620 / SGH-N625 / SGH-N626 / SGH-N628 / SGH-N635 / SGH-P100 / SGH-P107 / SGH-P200 / SGH-P207 / SGH-P300 / SGH-P310 / SGH-P408 / SGH-P735 / SGH-P777 / SGH-P910 / SGH-P920 / SGH-P930 / SGH-P940 / SGH-Q200 / SGH-Q208 / SGH-Q300 / SGH-R208 / SGH-R210 / SGH-R220 / SGH-R225 / SGH-R225M / SGH-S300 / SGH-S300M / SGH-S307 / SGH-S400 / SGH-S400I / SGH-S401 / SGH-S401I / SGH-S501i / SGH-T100 / SGH-T108 / SGH-T200 / SGH-T208 / SGH-T209 / SGH-T219 / SGH-T309 / SGH-T319 / SGH-T329 / SGH-T400 / SGH-T408 / SGH-T410 / SGH-T439 / SGH-T500 / SGH-T509 / SGH-T519 (Trace) / SGH-T609 / SGH-T619 / SGH-T629 / SGH-T709 / SGH-T719 / SGH-T809 / SGH-U100 / SGH-U510 / SGH-U600 / SGH-U700 / SGH-U710 / SGH-V200 / SGH-V205 / SGH-V206 / SGH-V804 / SGH-X100 / SGH-X105 / SGH-X150 / SGH-X160 / SGH-X200 / SGH-X210 / SGH-X300 / SGH-X425 / SGH-X426 / SGH-X427 / SGH-X427M / SGH-X460 / SGH-X461 / SGH-X475 / SGH-X480 / SGH-X481 / SGH-X495 / SGH-X496 / SGH-X497 / SGH-X500 / SGH-X506 / SGH-X507 / SGH-X510 / SGH-X520 / SGH-X530 / SGH-X540 / SGH-X550 / SGH-X600 / SGH-X620 / SGH-X630 / SGH-X640 / SGH-X650 / SGH-X660 / SGH-X670 / SGH-X680 / SGH-X680V / SGH-X700 / SGH-X800 / SGH-X820 / SGH-X830 / SGH-Z150 / SGH-Z230 / SGH-Z240 / SGH-Z360 / SGH-Z370 / SGH-Z400 / SGH-Z510 / SGH-Z510i / SGH-Z540 / SGH-Z560 / SGH-Z620 / SGH-Z650i / SGH-Z710 / SGH-Z720 / SGH-ZV40 / SPH-A110 / SPH-A120 / SPH-A303 / SPH-A400 / SPH-A420 / SPH-A460 / SPH-A500 / SPH-A503 / SPH-A560 / SPH-A580 / SPH-A600 / SPH-A620 / SPH-A640 / SPH-A660 / SPH-A680 / SPH-A700 / SPH-A740 / SPH-A760 / SPH-A790 / SPH-A800 / SPH-A820 / SPH-A840 / SPH-A880 / SPH-A900 / SPH-A920 / SPH-A940 / SPH-A940 (MM-A940) / SPH-A960 / SPH-M500 / SPH-M610 / SPH-M620 / SPH-N200 / SPH-N240 / SPH-N270 / SPH-N400 / SPH-U510 / Stripe / Sync / Tbird / The Ultra Edition 11.8 / The Ultra Edition 12.1 / The Ultra Edition 12.9 / The Ultra Edition 13.8 / The Ultra Edition 5.9 / The Ultra Edition 6.9 / The Ultra Edition 9.9 / The Ultra Edition II 10.9 / The Ultra Messaging / The Ultra Music Edition / The Wafer / Trace / Upstage / VGA-1000 / VGA1000 / VI-660 / VM-A680 / WEP150 / WEP170 / WEP180 / WEP185 / WEP200 / WEP410 / WEP500 / Access / Ace / Beat / Black Jack II / Blast / Cricket / DM-S105 / Duos / Fin / FlipShot / Giorgio Armani / Gleam / Glyde / Hue / Impact B / Instinct / Juke / Katalyst / Luxe / Messenger / miCoach / Muse / Musicall SGH-F408 / Musicall SGH-i458B / MyShot / Mysto / Omnia / Qbowl / SCH-R200 / SCH-R210 / SCH-R300 / SCH-R410 / SCH-R430 / SCH-R450 / SCH-R500 / SCH-R610 / SCH-U470 / SCH-U700 / SCH-U706 / SCH-U800 / SCH-U900 / SCH-U908 / SCH-U940 / SGH-A117 / SGH-A127 / SGH-A226 / SGH-A227 / SGH-A516 / SGH-A517 / SGH-A736 / SGH-A737 / SGH-A746 / SGH-A747 / SGH-A827 / SGH-B100 / SGH-B110 / SGH-B130 / SGH-B200 / SGH-B300 / SGH-B510 / SGH-C180 / SGH-C250 / SGH-C450 / SGH-D780 / SGH-D880 / SGH-D888 / SGH-D980 / SGH-D988 / SGH-E210 / SGH-E215 / SGH-E590 / SGH-E950 / SGH-F110 / SGH-F200 / SGH-F210 / SGH-F218 / SGH-F250 / SGH-F258 / SGH-F268 / SGH-F330 / SGH-F338 / SGH-F400 / SGH-F480 / SGH-F488 / SGH-F490 / SGH-F498 / SGH-F500 / SGH-F700 / SGH-G400 / SGH-G600 / SGH-G608 / SGH-G800 / SGH-G808 / SGH-i200 /

[SGH-i325](#) / [SGH-i400](#) / [SGH-i450](#) / [SGH-i458](#) / [SGH-i458P](#) / [SGH-i520](#) / [SGH-i550](#) / [SGH-i560](#) / [SGH-i568](#) / [SGH-i608](#) / [SGH-i610](#) / [SGH-i616](#) / [SGH-i617](#) / [SGH-i640](#) / [SGH-i640v](#) / [SGH-i740](#) / [SGH-i760](#) / [SGH-i780](#) / [SGH-i900](#) / [SGH-J150](#) / [SGH-J200](#) / [SGH-J210](#) / [SGH-J400](#) / [SGH-J610](#) / [SGH-J630](#) / [SGH-J700](#) / [SGH-J708](#) / [SGH-J750](#) / [SGH-J758](#) / [SGH-J800](#) / [SGH-L170](#) / [SGH-L310](#) / [SGH-L400](#) / [SGH-L600](#) / [SGH-L700](#) / [SGH-L760](#) / [SGH-L768](#) / [SGH-L770](#) / [SGH-L870](#) / [SGH-M110](#) / [SGH-M130](#) / [SGH-M140](#) / [SGH-M150](#) / [SGH-M300](#) / [SGH-M305](#) / [SGH-M310](#) / [SGH-M520](#) / [SGH-M600](#) / [SGH-M610](#) / [SGH-M618](#) / [SGH-M620](#) / [SGH-M800](#) / [SGH-P180](#) / [SGH-P220](#) / [SGH-P260](#) / [SGH-P520](#) / [SGH-P720](#) / [SGH-P960](#) / [SGH-R200](#) / [SGH-R500](#) / [SGH-S7330](#) / [SGH-T229](#) / [SGH-T309](#) / [SGH-T339](#) / [SGH-T409](#) / [SGH-T429](#) / [SGH-T439](#) / [SGH-T539](#) / [SGH-T639](#) / [SGH-T729](#) / [SGH-T737](#) / [SGH-T739](#) / [SGH-T747](#) / [SGH-T819](#) / [SGH-U470](#) / [SGH-U608](#) / [SGH-U708](#) / [SGH-U908](#) / [Slash](#) / [SLM](#) / [Solid](#) / [Soul](#) / [Soul B](#) / [Spex](#) / [SPH-A513](#) / [SPH-A523](#) / [SPH-i325](#) / [SPH-M210](#) / [SPH-M300](#) / [SPH-M305](#) / [SPH-M310](#) / [SPH-M510](#) / [SPH-M520](#) / [SPH-M800](#) / [SPH-Z400](#) / [Steel](#) / [Tocco](#) / [TOUCHWiZ](#) / [Ultra Edition III 12.9](#)

Sandisk

[Sansa](#) / [Sansa Clip](#) / [Sansa Shaker](#)

Sanyo

[4930](#) / [Katana](#) / [Katana DLX](#) / [Katana II](#) / [MM-5600](#) / [MM-7400](#) / [MM-7500](#) / [MM-8300](#) / [MM-9000](#) / [MVP EV-DO](#) / [PM-8200](#) / [PRO-200](#) / [PRO-700](#) / [RL-2000](#) / [RL-2500](#) / [RL-4920](#) / [RL-4930](#) / [RL-7300](#) / [S1](#) / [SCP-200](#) / [SCP-2300](#) / [SCP-3100](#) / [SCP-3200](#) / [SCP-4300](#) / [SCP-4900](#) / [SCP-4920](#) / [SCP-4930](#) / [SCP-5300](#) / [SCP-5400](#) / [SCP-5500](#) / [SCP-6600](#) / [SCP-7050](#) / [SCP-7200](#) / [SCP-7300](#) / [SCP-8100](#) / [SCP-8200](#) / [SCP-8400](#) / [VI-2300](#) / [VM-4500](#) / [VM-5500](#)

Sharp

[Willcom WS003SH](#) / [Willcom WS007SH](#)

Sidekick

[LX](#) / [Slide](#)

Siemens

[SX-56](#)

SoftBank

[X01HT](#)

Sony

[Nav-U NV-U52](#) / [Nav-U NV-U70](#) / [Nav-U NV-U71T](#) / [Nav-U NV-U72T](#) / [Nav-U NV-U73T](#) / [Nav-U NV-U82](#) / [Nav-U NV-U83T](#) / [Nav-U NV-U92T](#) / [PSP](#) / [Reader](#) / [Walkman NW-E405](#) / [Walkman NW-E407](#) / [Walkman NW-E507](#) / [Walkman NW-S205F](#)

Sony Ericsson

[C702](#) / [C702a](#) / [C702c](#) / [C902](#) / [C902c](#) / [C905](#) / [D750](#) / [D750i](#) / [F305](#) / [G502](#) / [G700](#) / [G700c](#) / [G900](#) / [HBH-DS200](#) / [HBH-DS220](#) / [HBH-DS970](#) / [HBH-DS980](#) / [HBH-GV435](#) / [HBH-GV435a](#) / [HBH-IV835](#) / [HBH-IV840](#) / [HBH-PV700](#) / [HBH-PV702](#) / [HBH-PV705](#) / [HBH-PV708](#) / [HBH-PV710](#) / [HBH-PV712](#) / [HBH-PV770](#) / [HCB-100E](#) / [HCB-105](#) / [HCB-120](#) / [J100](#) / [J100a](#) / [J100c](#) / [J100i](#) / [J110a](#) / [J110c](#) / [J110i](#) / [J120c](#) / [J120i](#) / [J132](#) / [J220](#) / [J220a](#) / [J220c](#) / [J220i](#) / [J221](#) / [J230](#) /

J230a / J230c / J230i / K200a / K200c / K200i / K205a / K205i / K220c / K220i / K310 / K310a / K310c / K310i / K320i / K330 / K510 / K510a / K510c / K510i / K530c / K530i / K550 / K550c / K550i / K550im / K610 / K610c / K610i / K610im / K618 / K618i / K630i / K660 / K660i / K750 / K750c / K750i / K758c / K770i / K790 / K790a / K790c / K790i / K800 / K800c / K800i / K810i / K818c / K850 / K850i / K858c / M600i / M608 / M608c / MBR-100 / P1c / P1i / P990c / P990i / R300 / R306 / R306a / R306c / S302 / S500 / S500c / S500i / S600i / T250a / T250i / T258c / T270i / T280a / T303 / T303c / T650i / T658c / V630i / V640i / W200 / W200a / W200c / W200i / W300 / W300c / W300i / W302 / W350a / W350c / W350i / W380a / W380c / W380i / W550c / W550i / W580c / W580i / W580im / W595 / W600 / W600c / W600i / W610 / W610c / W610i / W618c / W660 / W660i / W700 / W700c / W700i / W710 / W710c / W710i / W712 / W760c / W760i / W800 / W800c / W800i / W810 / W810c / W810i / W830 / W830c / W830i / W850 / W850i / W850im / W880 / W880i / W888c / W890i / W900 / W900c / W900i / W902 / W908c / W910 / W910i / W950 / W950c / W950i / W958c / W960 / W960i / W980 / W980i / Z250a / Z250i / Z300a / Z300c / Z300i / Z310a / Z310i / Z320a / Z320i / Z520a / Z520c / Z520i / Z525 / Z525a / Z525i / Z530 / Z530c / Z530i / Z550 / Z550a / Z550c / Z550i / Z555i / Z558 / Z558c / Z558i / Z610 / Z610i / Z710 / Z710c / Z710i / Z712 / Z750 / Z750a / Z750i / Z770i / Z780a / Z780i

TomTom

Go / Go 300 / Go 500 / Go 510 / Go 520 / Go 700 / Go 710 / Go 720 / Go 730 / Go 900 / Go 910 / Go 920 / Go 920T / Go 930 / MK II / Mobile 5 / Navigator 5 / Navigator 6 / One / One XL / Rider / Rider 2nd Edition

Toshiba

CDM9950SP / Gigabeat F10 / Gigabeat F20 / Gigabeat F40 / Gigabeat F60 / Gigabeat S30 / Gigabeat S60 / MEU202-SL / Portege G500 / Portege G900 / VM4050

UBiQUiO

501 / 503G

VuGo

VuGo

Wi-Gear

iMuffs

Extra Connectors

Six extra connectors are available for even more compatibility and they plug right into the USB socket in The Sanctuary. Now you can charge your PSP and Nintendo game consoles, certain digital cameras, Motorola phones and even more devices with via a second mini-USB connector.

Mini USB - Requires extra connector

Note: Mini-USB is already included in the built-in connectors so this is only required if you wish to charge two Mini-USB devices at the same time.

Motorola Narrow - Requires extra connector

ROKR E1 / E815 / V200 / V265 / V266 / V276 / V300 / V330 / V400 / V500 / V505 / V525 / V540 / V547 / V551 / V555 / V557 / V600 / V710 / V810 / T720i / T722 / T722i / T725 / V60 / V60c / V60i / V60g / V60t / V66 / V70 / V120 / V120c / V120e / V120t / V120x / C232 / Timeport / 270 / 270c / 280 / 280g / HS815 / HS820 / H850 / HF820 / H850 / HF820 / HS850

Motorola Wide - Requires extra connector

i930 / i920 / i885 / i880 / i870 / i860 / i855 / i850 / i836 / i836 / i833 / i830 / i760 / i736 / i733 / i730 / i710 / i670 / i615 / i605 / i580 / i560 / i530 / i355 / i325IS / i315 / i305 / i285 / i275 / i265 / i215 / i205

Nintendo DS - Requires extra connector

Nintendo DS portable game console

Nintendo DS Lite - Requires extra connector

Nintendo DS Lite portable game console

PSP - Requires extra connector

PlayStation Portable (PSP); also compatible with the following items:

Apex Digital E2GO / Creative Nomad : Jukebox 2 / Jukebox 3 / Zen NX / Zen USB 2.0 / Jukebox Zen Xtra / Creative Zen : MuVo 2 / MuVo 2 FM / Portable Media Center / Touch / Vision / HP PhotoSmart R927 / iRiver : H320 / H340 / Kodak : DC4800 / DX6490 / DX7440 / DX7590 / DX7630 / EasyShare M1033 / EasyShare M763 / EasyShare M863 / EasyShare M873 / EasyShare M883 / EasyShare M893 IS / EasyShare P712 / EasyShare V1003 / EasyShare V1073 / EasyShare V1233 / EasyShare V1253 / EasyShare V1273 / EasyShare V530 / EasyShare V550 / EasyShare V570 / EasyShare V603 / EasyShare V610 / EasyShare V705 / EasyShare V803 / EasyShare-One / 4 MP / EasyShare-One / 6 MP / LS443 / LS633 / LS743 / LS753 / LS755 / M753 / M853 / M873 / M883 / P850 / P880 / Z730 / Z7590 / Z760 / Philips GoGear HDD082-17 / Sharp : Willcom WS003SH / Willcom WS007SH / Sony : Nav-U NV-U52 / Nav-U NV-U70 / Nav-U NV-U71T / Nav-U NV-U72T / Nav-U NV-U73T / Nav-U NV-U82 / Nav-U NV-U83T / Nav-U NV-U92T / Reader / TomTom : Go / Go 300 / Go 500 / Go 510 / Go 700 / Go 710 / Go 900 / Go 910 / MK II / Mobile 5 / Navigator 5 / Navigator 6 / Rider / Rider 2nd Edition / Toshiba : Gigabeat F10 / Gigabeat F20 / Gigabeat F40 / Gigabeat F60 / Gigabeat S30 / Gigabeat S60

Samsung A2

Access / Ace / Beat / Black Jack II / Blast / Cricket / DM-S105 / Duos / Fin / FlipShot / Giorgio Armani / Gleam / Glyde / Hue / Impact B / Instinct / Juke / Katalyst / Luxe / Messenger / miCoach / Muse / Musically SGH-F408 / Musically SGH-i458B / MyShot / Mysto / Omnia / Qbowl / SCH-R200 / SCH-R210 / SCH-R300 / SCH-R410 / SCH-R430 / SCH-R450 / SCH-R500 / SCH-R610 / SCH-U470 / SCH-U700 / SCH-U706 / SCH-U800 / SCH-U900 / SCH-U908 / SCH-U940 / SGH-A117 / SGH-A127 / SGH-A226 / SGH-A227 / SGH-A516 / SGH-A517 / SGH-A736 / SGH-A737 / SGH-A746 / SGH-A747 / SGH-A827 / SGH-B100 / SGH-B110 / SGH-B130 / SGH-B200 / SGH-B300 / SGH-B510 / SGH-C180 / SGH-C250 / SGH-C450 / SGH-D780 / SGH-D880 / SGH-D888 / SGH-D980 / SGH-D988 / SGH-E210 / SGH-E215 / SGH-E590 / SGH-E950 / SGH-F110 / SGH-F200 / SGH-F210 / SGH-F218 / SGH-F250 / SGH-F258 / SGH-F268 / SGH-F330 / SGH-F338 / SGH-F400 / SGH-F480 / SGH-F488 / SGH-F490 / SGH-F498 / SGH-F500 / SGH-F700 / SGH-G400 / SGH-G600 / SGH-G608 / SGH-G800 / SGH-G808 / SGH-i200 / SGH-i325 / SGH-i400 / SGH-i450 / SGH-i458 / SGH-i458P / SGH-i520 / SGH-i550 / SGH-i560 / SGH-i568 / SGH-i608 / SGH-i610 / SGH-i616 / SGH-i617 / SGH-i640 / SGH-i640v / SGH-i740 / SGH-i760 / SGH-i780 / SGH-i900 / SGH-J150 / SGH-J200 / SGH-J210 / SGH-J400 / SGH-J610 / SGH-J630 / SGH-J700 / SGH-J708 / SGH-J750 / SGH-J758 / SGH-J800 / SGH-L170 / SGH-L310 / SGH-L400 / SGH-L600 / SGH-L700 / SGH-L760 / SGH-L768 / SGH-L770 / SGH-L870 / SGH-M110 / SGH-M130 / SGH-M140 / SGH-M150 / SGH-M300 / SGH-M305 / SGH-M310 / SGH-M520 / SGH-M600 / SGH-M610 / SGH-M618 / SGH-M620 / SGH-M800 / SGH-P180 / SGH-P220 / SGH-P260 / SGH-P520 / SGH-P720 / SGH-P960 / SGH-R200 / SGH-R500 / SGH-S7330 / SGH-T229 / SGH-T309 / SGH-T339 / SGH-T409 / SGH-T429 / SGH-T439 / SGH-T539 / SGH-T639 / SGH-T729 / SGH-T737 / SGH-T739 / SGH-T747 / SGH-T819 / SGH-U470 / SGH-U608 / SGH-U708 / SGH-U908 / Slash / SLM / Solid / Soul / Soul B / Spex / SPH-A513 / SPH-A523 / SPH-i325 / SPH-M210 / SPH-M300 / SPH-M305 / SPH-M310 / SPH-M510 / SPH-M520 / SPH-M800 / SPH-Z400 / Steel / Tocco / TOUCHWiZ / Ultra Edition III 12.9